BOTTLE COOLER

CONTENTS

- SAFETY PRECAUTIONS ..... 1 ~ 3
- HOW TO USE ..... 4 ~ 5
- CLEANING 5
- IN CASE OF THE FOLLOWING ----------6
- BEFORE REQUESTING SERVICE 7

Please read these instructions completely before operating the units.

SAFETY PRECAUTIONS

- To ensure proper use, please thoroughly study thesesAFETY PRECAUTIONs before operating the unit.
- The purpose of the safety precautions in this manual is to ensure safe and correct use of the unit to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into wARNINGsand cAUTIONS.caseswhere improper handling of the unit could lead to death or serious injury are listed under the"___WARNING" heading. However,thecases· listed under the"__CAUTION" heading could also le- ad to serious results. To ensure the safety, adhere strictly to both types of safety precautions.

·/··\· WARNING	Improper handling of the unit could lead to death or serious injury.
·/·\· CAUTION	Improperhandling of the unitcould lead to serious results depending on the circumstances.

- Text set off by the exclamation mark contains information that should be strictly adhered to.
- After reading the instruction manual, store itan easily accessible place where the user(s) of this product can easily find it.

◆ PRECAUTIONS FOR INSTALLATION

WARNING


Installation should be performed only by the dealerora qualified expert.Attempting to instal lth e unit yoursel f coul d resul tin wate r leakage, refrigerant leakage, electrical shock, or fire.

◆ PRECAUTIONS FOR USE

⚠WARNING


DON'T TAMPER

Al l repairs ,dis assembly an d modifications should be performed only by qualified technicians. Ai tempting to perform these yourself could result in a fire, malfunction, and injury




ELECTRICAL SHOCK HAZARDS

Never splash water directly onto the product or wash with water as short-circuit and electrical leakage could result.




DANGER OF EXPLOSION

Never put flammable or volatile substances into the unit as explosion and fire could result.




PROHIBITED

Do not damage, modify, excessively bend, strain, twist or bundle up the power cord. Also, placing heavy objects the power cord or squeezing it ina tight place could damage it, possible resulting in electrical shock or fire.




PROHIBITED

use a dedicated wall outlet. DO not use extension cords or convenience receptacle s as this could result in electrical shock, overheating and a fire.



FLAMMABLE

Never use flammable spray cans or leave flammable substances near the unit. Sparks from electrical switches could result in explosion and fire.



SAFETY PRECAUTIONS


⚠WARNING

The cooler is intended for storage and display of beer and beverages for sale. Do not use for other purpose than the intended as this could adversely affect items placed in the unit.




ROTATING DEVICE

Never attempt to insert fingers, sticks, etc. Into the cold air suction outlet. A circulation fan is rotating at high speed inside the outlet. Injury, electrical shock and improper operation could result.




PROHIBITED

For indoor use only. Using the unit in a location exposed to rain could result in electrical leakage and electrical shock.




PROHIBITED

Never place heavy objects or items containing water on top of the unit. Objects could fall down and cause injury and spilled water could deteriorate the insulation of electrical components and result in electrical leakage.




Install the unit in a location where the floor is sturdy enough to support the load of the unit. If the floor is not sturdy enough or installation is incorrectly performed, the unit could tip over and falling shelves and products could cause personal injury



CAUSION AGAINST EXPLOSION


If you find gas leakage, please don't touch the chest freezer,and close gas and open the door for ventilation. Gas leakage cause explosion, fire, and fire injury.



store the unit in a location where it is not exposed to rain. using a unit that has been exposed to rain could result in electrical leakage and electrical shock.



Away from hot air sources cooling performance is reduced if the unit is placed near heat sources such as hot plates and stove sand if it is exposed to direct sunlight.



Leave dis assembly and disposal of the unit to qualified experts.




Should the unit need temporary storage, make sure not to store the unit in a location where children play and take precautions so that the door cannot be completely closed. This will minimize the risk that a child becomes trapped inside the compartment.

SAFETY PRECAUTIONS

⚠WARNING


WELL VENTILATED PLACE

Please make more than10cm space between Chest freezer and wall. If there are no space, cooling capacity can drop down.




DANGER OF ELECTRICAL SHOCK

If installation in a damp location is unavoidable, also instal lan electrical leakage circuit breaker. If no electrical leakage circuit break er is installed, electrical shock could result.




PROHIBITED

Never hang from the door or climb onto the unit. The unit could tip over or fall and cause material damage or injury.




DISCONNECT POWER CORD PLUG FROM WALL OUTLET

Disconnect the power cord plug from the wall outlet before moving the unit and make sure that the power cord is not damaged during transport. A damaged power cord could result in electrical shock and/or fire.




DON'T PINCH FINGERS

Grasp the handle when closing the door. Holding at other positions could result in pinched fingers and injury.




Do not touch


Do not push hand against or apply excessive force to glass surfaces as the glass could break and cause injury.



when disconnecting the power cord plug from the wal loutlet, hold at the plug main body closet o the outlet. pulling the cord could cause wire breakage, possible resulting in overheating and fire.



Make sure that the unit does not tip over or fal lwhen it is moved. A falling unit could cause serious injury




PROHIBITED

Do not throw items onto the shelves and do not place items totaling more than 30Kg on eachshelf. The shelf could fall down, possibly cause injury.



Be sure attach and secure shelves correctly. An improperly attached shelf could fall downand cause injury.



HOWTO USE

BEFORE USE

- Remove shipping package, tape, etc, and leave doors open ventilation for a while.
- The unit is cleaned before shipment. However, clean the compartment interior once after delivery.
- Please insert power supply plug into the wall outlet ,singte-phale to cat voltage.
- Allow the unit to operate for about 1 hour to cool the compartment before placing items in the cooler.

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

- Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the compressor may be overloaded, and/or other damage may occur.

TEMPERATURE ADJUSTMENT

- Thermostat was adjusted using temperature at factory. To adjust it, turn right could cause temperature in showcase down. To raise the temperature, turn it left. Excessive refrigeration will increase electricity consumption unnecessarily.

DRAIN TRAY

- Defrosting is performed automatically and drain water is collected in the drain tray.
- Water is in the drain tray is evaporated automatically. In humidity, large amount of water in the drain tray, so please throw away drain water once a day.

EFFICIENT USE

please follow the below instruction, you could sove energy.

- To prevent cold air from escaping, open and close the door quickly and keep the door opened for as short a time as possible.
- Please install the unit in the place which is well-ventilated.

SHELF HEIGHT ADJUSTMENT

The shelf height can be adjusted.

Arrange the shelves in accordance with the dimensions of the items tobe placed in the cooler.

HOW TO USE

PLACING ITEMS IN THE SHOWCASE

This showcase employs a forced circulation of cold air system. If circulation of cold air is obstructed, the items will not be adequately refrigerated. Pay attention to the following points:

- Do not let items obstruct the cold air inlet and suction outlet.
- Place items so that they do not protrude from the shelves. The gap between the shelves and the door is used for circulation of cold air.
- Place items evenly on all shelves.


Please do not display goods on the bottom. please put goods on the shelf

THERMOSTAT INSTRUCTION

operation

control panel

The control panel is located below the door son the front of the appliance.



Turn on

I. Turn the power switch on.

I. set the temperature to the desired setting (see below).

2. close the door of the appliance.

3. connect the appliance to a mains power supply.

Note: The Cooling Light is illuminated when the appliance is chilling the interior cabinet.

4. Turn light switch On [I] or Off [O] as required.

set the operating Temperature

1. Press the SET button. The display will flash.

2. Press the ▲ or ▼ buttons to display the required temperature.

3. Press the SET button to store the temperature.

Manual Defrost

cooler feature an automatic defrost. However, should the appliance require an additional defrost period press and hold the ❄ button for6seconds.

Automatic defrost cycles are every 6 hours and last 20 minutes (factory defaults).


To stop the Defrost press and hold the ❄ button for6seconds.

Note: Ifa manual defrost is started this resets the automatic defrost timer. During defrost periods the Defrost light is illuminated.

WARNING

WARNING : Do not splash water directly onto the cooler and do not wash with water . short - circuit and electrical shock could result .

- clean the cooler regularly to keep it clean at all times .
- Never use polishing powder , soap powder , benzine , oil or hot water as these will damage the painting and plastic components .



2 CHECKS

To ensure the safety, perform the following checks after cleaning.
●Is the power cord plug firmly inserted into a dedicated wall outlet? Confirm that the plug is not abnormally hot.
●Check the power cord for cracks and damage. Should the slightest irregularity be observed, contact the dealer from whom you purchased this unit or our customer's service.

INCASE OF THE FOLLOWING

1 POWER FAILURE

Keep opening and closing of the door to a minimum.
Avoid placing new items in the cooler as this will raise the temperature inside the compartment.

2 WHEN NOT USED FOR A LONG PERIoD

Remove all items from the compartmentand disconnect the power cord plug from the wall outlet.
Clean the compartment interior and wipe away all water.
To prevent mold formation and bad smell, leave the door open to dry the compartment completely.

3 TRANSPORTATION

Disconnect the power cord plug from the wall outlet.
When moving the cooler, make sure that the feet do not damage the power cord.
Do not let the feet hit against floor steps, thresholds, etc.

4 TEMPORARY STORAGE

Affix a piece of wood, etc. Between the door and main unit to prevent complete closing of the door.
Make sure not to store the unused cooler at a location where children play.
Should a child enter the compartment and the door is closed, the child may not be able to open the door from the inside.

INSTRUCTION MANUAL

BEFORE REQUESTING SERVICE

Please check the following items if you encounter problems with the unit. If the problem continues after taking the proper remedial actions, disconnect the power cord plug from the wall outlet.
Transfer the items stored in the cooler to a box or other container. Then contact the dealer from whom you purchased this unit and be ready to provide information as listed in "REQUIRED INFORMATION" below.

CAUTION

To prevent any electrical shock hazards, do not disconnect the power cord plug from the wall outlet with wet hands.

190X260mm

BEFORE REQUESTING SERVICE

No refrigeration at all	●Is the power supply interrupted? ●Is the power cord plug disconnected from the walloutlet? ●Are the shop's power fuses blown and/or the circuit breaker activated?
Inadequate refrigeration	●Is the temperature setting appropriate? ●Are items obstructing the cold air inlet and suction outlet? ●Are stored items packed too tight? ● Is the door open or is it opened and closed frequently? ● Is the condenser clogged?
Excessive noise	●Are all feet in firm contact with the floor? ● Is the rear panel of the cooler contacting the wallorotherobjects? ●Are otherobjects in contact with the cooler?
condensation on cooler exterior	● Condensation may condense on the exterior and door during hot and humid days or depending on the place of installation. This occurs when the humidity is high and water particles in the air contact cold surfaces. This is normal.wipe away condensation with a dry cloth.

showcase sometimes stop running when thermostat turns off.

INSTRUCTION MANUAL

REQUIRED INFORMATION

Nature of malfunction
(as accurately as possible)

customer's name, address
phone number